

2 Port Operation (Bleed)

Connect to turbo
compressor inlet



Connect to boost source
you are bleeding from

3
Cap off

3 port operation (interrupt)

Connect to WG
actuator



Connect to turbo inlet
pipe

3
Connect to boost source